



#FeelsParenting.

## Safety and Cleaning Instructions for the LIINI® Home Bottle Warmer 230V

Dear Customer,

Thank you for choosing our 230V Bottle Warmer. We place great importance on your safety and the well-being of your family.

To ensure that you can use your device safely, it is important to carefully follow the safety and cleaning instructions below. **Improper use can pose serious risks!**

### Manual / User Guide

We have made a conscious decision to forego printed user manuals, thereby saving several metric tons of paper each year. At the same time, we can update our electronic user manual at any time, ensuring you always have the latest version on hand.

Even though much of the device's operation is intuitive, please take **5 minutes** to **read through the manual**. Following the instructions in the user manual is important so that you can enjoy the product for a long time, ensure everything works safely, and avoid unnecessary hassle.

You can find the **user manual** by scanning the **QR code** below (use your smartphone to scan it):



Available online: DE / EN / FR / IT

---

**Bankverbindung CHF:**  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

**Bankverbindung EUR:**  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

**Kontakt**  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: [www.LIINI.ch](http://www.LIINI.ch)  
E-Mail: [info@LIINI.ch](mailto:info@LIINI.ch)  
Tel: +41 79 559 06 02

**Rechtliches**  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7



#FeelsParenting.

## General Information

<b>Manufacturer</b>	LIINI GmbH Bahnhofstrasse 21 4571 Lüterkofen Switzerland
<b>Contact</b>	compliance@liini.ch
<b>Country of Origin</b>	China (CN)
<b>Certifications</b>	CE, FCC, MSDS, RoHS, UN 38.3
<b>EU Authorized Representative</b>	ProductIP AR Services Galvanistraat 1 6716 AE Ede The Netherlands (authorities only)
<b>WEEE Registration Number (DE)</b>	74241330  Foundation for the Register of Waste Electrical and Electronic Equipment Nordostpark 72 90411 Nuremberg
<b>WEEE Registration Number (AT)</b>	9008392342860  Federal Ministry for Climate Protection, Environment, Energy, Mobility, Innovation, and Technology (BMK) Radetzkystraße 2 1030 Vienna
<b>WEEE Registration Number (LU)</b>	MA1403

Bankverbindung CHF:  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

Bankverbindung EUR:  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

Kontakt  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: www.LIINI.ch  
E-Mail: info@LIINI.ch  
Tel: +41 79 559 06 02

Rechtliches  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7



#Feels Parenting.

	ecotrel asbl 11, Boulevard du Jazz 4370 Belvaux,
<b>WEEE Registration Number (NL)</b>	42125  Stitching OPEN 7 Baron de Coubertinlaan 2719 EN Zoetermeer

<b>WEEE Registration Number (PL)</b>	000642512  Main Inspectorate for Environmental Protection Chmielna 132, Suite 331 00-805 Warsaw
<b>WEEE Registration Number (CZ)</b>	04407/15-ECZ  ASEKOL a.s. 2062/8 Czechoslovak Exile Street 143 00 Prague 4
<b>WEEE Registration Number (SE)</b>	SEBATT00003321  Swedish Environmental Protection Agency Virkesvägen 2 Hammarby Sjöstad Stockholm
<b>WEEE Registration Number (UK)</b>	WEE/MM6698AA  Office for Product Safety and Standards 4th Floor, Multistorey Building 18 The Priory Queensway Birmingham, B4 6BS

Bankverbindung CHF:  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

Bankverbindung EUR:  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

Kontakt  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: www.LIINI.ch  
E-Mail: info@LIINI.ch  
Tel: +41 79 559 06 02

Rechtliches  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7



#FeelsParenting.

## General Safety Instructions (GPSR)

Please observe the following safety instructions:

- The LIINI® Home bottle warmer is intended for indoor use only.
- The device must only be operated from properly installed electrical outlets with the line voltage specified on the nameplate.
- The device is not a toy and must never be operated by children.
- Children must never play near the device without supervision.
- The product must be operated exclusively by adults.
- Before each use, check the device for visible damage.
- Never use the device if the cable, power plug, or housing is damaged.
- The power cord must not be kinked, pinched, or routed over sharp edges.
- Never pull on the cord to disconnect the device from the power source.
- The device must never be submerged in water or other liquids.
- Never clean the device under running water.
- Never use the device outdoors or in damp environments.
- The device must not be operated in the immediate vicinity of bathtubs, showers, sinks, or other sources of water.
- Do not open, modify, or attempt to repair the device yourself.
- Repairs may only be performed by authorized technicians.
- The device must only be operated on a stable, level, and heat-resistant surface.
- Ventilation openings must never be covered.
- The device must not be operated in direct sunlight.
- LIINI® Home may only be used at ambient temperatures between 4 °C and 40 °C.
- The device is intended exclusively for warming and keeping baby bottles warm.
- Use only baby bottles that are compatible with the device as specified in the user manual.

—●— The baby bottle must be properly screwed onto the device before each heating cycle. ————

**Bankverbindung CHF:**  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

**Bankverbindung EUR:**  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

**Kontakt**  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: [www.LIINI.ch](http://www.LIINI.ch)  
E-Mail: [info@LIINI.ch](mailto:info@LIINI.ch)  
Tel: +41 79 559 06 02

**Rechtliches**  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7



#FeelsParenting.

- Do not touch the heating surface during or immediately after use. There is a risk of burns.
- Before each feeding, check the temperature of the baby food using the wrist test or a suitable liquid thermometer.
- Baby food must never be overheated.
- The device must never be used with damaged seals.
- Seals are wear parts and must be checked regularly and replaced as needed.
- Use only genuine LIINI® replacement parts.
- Never clean the device with harsh or abrasive cleaning agents.
- If you notice any unusual odors, smoke, or malfunctions, unplug the appliance immediately.

## Cleaning Instructions

### Cleaning the heating area (heating plate)

- Turn the appliance off completely.
- Unplug the power cord.
- Allow the appliance to cool completely.
- Clean the heating surface with a soft, slightly damp cloth.
- Then wipe it down with a dry cloth.
- Allow it to dry completely before the next use.

LIINI®'s high-quality cleaning and disinfecting wipes offer an efficient and convenient solution for thoroughly cleaning and disinfecting our products. They're ideal for cleaning our bottle and baby food warmers, breast pumps, and accessories—or your baby bottles on the go.



**Bankverbindung CHF:**  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

**Bankverbindung EUR:**  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

**Kontakt**  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: [www.LIINI.ch](http://www.LIINI.ch)  
E-Mail: [info@LIINI.ch](mailto:info@LIINI.ch)  
Tel: +41 79 559 06 02

**Rechtliches**  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7



#FeelsParenting.

- Made from bamboo: The wipes are made from bamboo viscose—for the environment and our children’s future
- 2-in-1 protection: Removes dirt and eliminates up to 99.9% of all bacteria, viruses, and fungi
- Fast and effective: Thanks to their special formula, the wipes work in just a few seconds and leave no residue
- Versatile: Suitable for the heating compartment of bottle and baby food warmers, as well as the components of our breast pump
- Fragrance-free: Cleans and disinfects without artificial scents or fragrances
- Alcohol-free: Alcohol-free for your baby
- Compostable: Simply toss the wipes with your green waste

### Cleaning for Stubborn Stains

For heavy soiling, such as limescale deposits, you can let a water-vinegar mixture sit overnight. Please proceed as follows:

1. Fill the heating compartment of the bottle or baby food warmer halfway with boiled water.
2. Now add a little apple cider vinegar to the boiling water. Make sure to leave a 10 mm gap between the mixture and the edge of the warming compartment. This ensures that the water-vinegar mixture doesn’t overflow and enter the appliance.
3. If you’ve spilled any of the mixture, remove the residue with a wet wipe and dry the housing. Otherwise, the housing’s color may change.
4. You can now let the mixture sit overnight. Make sure the product is out of reach of your children.
5. The next day, you can pour out the solution and wipe away the residue with a damp cloth.
6. The appliance must be allowed to dry completely.

### Cleaning the Housing

To clean the housing, simply wipe away any milk or baby food residue with a damp cloth. Do not use any harsh cleaning agents, as this can damage the housing. The cloth must not be dripping wet, as water could otherwise enter the device (see Safety Instructions, page 1).

### Cleaning the Lid of the LIINI® Home

The lid of the LIINI Home must **not be cleaned in the sterilizer**.

The high temperatures in the sterilizer can cause the lid to warp. As a result, it may no longer close properly, and the proper functioning of the LIINI Home can no longer be guaranteed.

Recommended cleaning method for the lid:

- Wash the lid by hand with warm water and mild dish soap.
- Then rinse thoroughly.
- Then let it air dry completely.

### Information on the WEEE Directive 2012/19/EU

Bankverbindung CHF:  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

Bankverbindung EUR:  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

Kontakt  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: www.LIINI.ch  
E-Mail: info@LIINI.ch  
Tel: +41 79 559 06 02

Rechtliches  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7



#Feels Parenting.

## Meaning of the crossed-out trash can symbol



All of our electronic devices (bottle warmers, baby food warmers, sleep aids) are marked with the crossed-out trash can symbol.

The crossed-out trash can symbol means that **you are legally required** to dispose of these devices separately from unsorted household waste; in other words, old devices must be disposed of separately from regular household trash. Non-built-in batteries or rechargeable batteries must be removed beforehand and disposed of separately.

A bar beneath the trash can symbol indicates that the product was placed on the market after August 13, 2005.

## Options for Returning Old Devices (WEEE Directive 2012/19/EU)

Owners of waste electrical and electronic equipment can return it through the return or collection options established and made available by public waste management authorities to ensure proper disposal.

## Personal Data (WEEE Directive 2012/19/EU)

All end users of waste electrical and electronic equipment are advised that they are personally responsible for deleting any personal data from the waste equipment to be disposed of.

---

**Bankverbindung CHF:**  
IBAN: CH06 0021 0210 1087 0101 V  
BIC / SWIFT: UBSWCHZH80A

**Bankverbindung EUR:**  
IBAN: CH23 0021 0210 1087 0160 X  
BIC / SWIFT: UBSWCHZH80A

**Kontakt**  
LIINI GmbH  
Bahnhofstrasse 21  
4571 Lüterkofen  
Web: [www.LIINI.ch](http://www.LIINI.ch)  
E-Mail: [info@LIINI.ch](mailto:info@LIINI.ch)  
Tel: +41 79 559 06 02

**Rechtliches**  
UID: CHE-131.522.878 MWST  
Steuernr. DE: 09417/18455  
Umsatzsteuer-ID: DE352084049  
EORI-Nr: DE905090565529397  
Zollkonto ZAZ: 19867-7